

# FiberPatrol® FP400 Zone Kit



F4KT0200

The FiberPatrol FP400 Zone Kit consists of one Start Module and one End Module, which are used to define a detection zone:


- The Start Module functions as a coupler, splitting/summing transmitted light to/from sensing fibers.
- The End Module functions as a mirror, reflecting light from the end of each sensing fiber.

### General Specifications

- Kit contents:
  - 1 Start Module with 4 SC/APC connectors
  - 1 End Module (two mirrors, each with one pigtail that is terminated with an SC/APC connector)
- Includes all required consumables

**Note:** Pigtails are removed at installation time and reused for connecting lead-in cable to the FP400 processor.

**Start Module**                      +                      **End Module**                      =                      **1 Zone Kit**



See the FiberPatrol® FP400 Datasheet for a full system description.