



1






<https://senstar.com/product-resources/multisensor-help>

2



3



PoE Switch

192.168.0.xxx

192.168.0.150

4



senstar.com




Network Manager



UCM

5



Senstar MultiSensor

PoE Switch

PC

Network Manager

UCM

